

1.) TEAR OUT THE OLD GASKET,  
CUT AND SCRAPE OUT THE OLD SCREEN  
AND ADHESIVE MATERIAL ALL THE WAY  
DOWN TO BARE METAL.

2.) CLEAN THE BARE METAL WITH ALCOHOL  
SO THE ADHESIVE STRIP ON THE NEW  
GASKET WILL STICK BETTER.

3.) MAKE SURE TO INSTALL THE GASKET WITH  
THE GROOVE FACING INWARD, SO IT WILL  
RECIEVE THE SCREEN.

