



### Elite Seal

Model #	A	B	C	D	E *
E-118	1.125	1.75-3	3.000	6.400	3.300
E-114	1.250	1.750-2.75	3.000	6.400	3.300
		3-3.25	3.500	6.400	3.300
		3.500	3.800	6.400	3.300
E-138	1.375	2-2.75	3.000	6.400	3.300
		3-3.25	3.500	6.400	3.300
		3.500	3.800	6.400	3.300
E-112	1.500	2-2.75	3.000	6.400	3.300
		3-3.25	3.500	6.400	3.300
		3.500	3.800	6.400	3.300
E-134	1.750	2.5-3.25	3.500	6.400	3.800
		3.500	3.800	6.400	3.800
		3.75-4	4.500	8.400	3.800
		4.500	5.000	8.400	3.800
E-200	2.000	2.5-3.75	4.000	8.750	4.500
		4.000	4.500	8.750	4.500
		4.500	5.000	8.750	4.500
E-214	2.250	3.500	4.000	8.750	4.500
		3.750-4	4.500	8.750	4.500

		4.500	5.000	8.750	4.500
<b>E-212</b>	2.500	3.250-3.5	4.000	8.750	4.500
		3.75-4	4.500	8.750	4.500
		4.250-4.5	5.000	8.750	4.500
		5	5.500	8.750	4.500
		5.5	6.000	8.750	4.500
<b>E-234</b>	2.750	3.5-5	5.500	8.750	4.500
		5.500	6.000	8.750	4.500
		6.000	6.500	10.550	4.500
<b>E-300</b>	3.000	4-5	5.500	8.750	4.500
		5.500	6.000	8.750	4.500
		6.000	6.500	10.550	4.500
<b>E-314</b>	3.250	4-5.5	6.000	8.750	4.500
		6.000	6.500	10.550	4.500
		6.625	7.000	10.550	4.500
<b>E-312</b>	3.500	4.5-6	6.000	8.750	4.500
		6.625	7.000	10.550	4.500
		7.000	7.500	12.550	4.500
<b>E-334</b>	3.750	5-5.5	6.000	8.750	4.500
		6.000	6.500	10.550	4.500
		6.625	7.000	10.550	4.500
		7.000	7.500	12.550	4.500
		8.000	8.500	12.550	4.500
<b>E-400</b>	4.000	5.500	6.000	8.750	4.700
		6.000	6.500	10.550	4.700
		6.625	7.000	10.550	4.700
		7.000	7.500	12.550	4.700
		8.000	8.500	12.550	4.700
<b>E-412</b>	4.500	6-6.625	7.000	10.550	4.700
		7.000	7.500	12.550	4.700
		8.000	8.500	12.550	4.700
<b>E-500</b>	5.000	6.625-7	7.500	12.550	4.700
		8.000	8.500	12.550	4.700
		10.000	11.000	12.550	4.700

\* Minimum clearance between stern tube and coupling.

If seal body is close to the stern tube, you must insure shaft is center to it.

Elite Seal (Metric)					
	Shaft	Stern tube (OE)			
Model #	A	B	C	D	E *
<b>E-20MM</b>	20	44-57	76	163	84
<b>E-30MM</b>	30	44-70	76	163	84
		75	89	163	84

		90	97	163	84
<b>E-35MM</b>	35	50-70	76	163	84
		75-83	89	163	84
		90	97	163	84
<b>E-40MM</b>	40	51-70	76	163	84
		75-83	89	163	84
		90	97	163	84
<b>E-45MM</b>	45	64-83	89	163	97
		90	97	163	97
		95-102	114	213	97
		114	127	213	97
<b>E-50MM</b>	50	64-95	102	222	122
		102	114	222	122
		114	127	222	122
<b>E-60MM</b>	60	90	102	222	122
		95-102	114	222	122
		114	127	222	122
<b>E-65MM</b>	65	83-90	102	222	122
		95-102	114	222	122
		108-114	127	222	122
		127	140	222	122
		140	152	222	122
<b>E-70MM</b>	70	90-127	140	222	122
		140	152	222	122
		152	165	268	122
<b>E-75MM</b>	75	102-127	140	222	122
		140	152	222	122
		152	165	268	122
<b>E-80MM</b>	80	102-140	152	222	122
		152	165	268	122
		168	178	268	122
<b>E-85MM</b>	85	114-152	152	222	122
		168	178	268	122
		178	191	319	122
<b>E-90MM</b>	90	127-140	152	222	122
		152	165	268	122
		168	178	319	122
		178	191	319	122
		203	216	319	122
<b>E-100MM</b>	100	140	152	222	130
		152	165	268	130
		168	178	319	130
		178	191	319	130

		203	216	319	130
<b>E-110MM</b>	110.000	152-168	178	268	130
		178	191	319	130
		203	216	319	130
<b>E-120MM</b>	120.000	168-178	191	319	130
		203	216	319	130
		254	279	319	130
<b>E-130MM</b>	130	168-178	191	319	130
		203	216	319	130
		254	279	319	130
		305	324	319	130
<b>* Minimum clearance between stern tube and coupling.</b>					
<b>If seal body is close to the stern tube, you must insure shaft is center to it.</b>					