## WAKESHADE Clamp Size Chart

## To determine the right size clamp for your boat follow these steps:

- 1. Print this page to actual size or 100% scale.
- 2. Cut out the length chart along the dotted lines.
- 3. Measure the circumference of the bar where the clamps will attach.

\*If our standard clamp sizes don't work, let us know. We can create the size you need.

- 4. Select the clamp size that fits your tower or T-top bar.
- 5. If the circumference is between two clamp size options, please select the size that is closest to the circumference of your bar.

SIZES		Extra Small Clamp Kit, C4			Small Clamp Kit, C1				Me C2	dium (	Clamp Ki	t,	Large Clamp Kit, C3			
The clamps come with inserts	CLAMP SIZE	1.25"	1.375"	1.5"	1.625"	1.75"	1.875"	2"	2.125"	2.25"	2.375"	2.5"	2.625"	2.75"	2.875"	3"
used to accommodate a range of tower and t-top bar sizes.	CIRCUMFERENCE	3.93"	4.32"	4.71"	5.1"	5.5"	5.89"	6.28"	6.68"	7.0"	7.46"	7.85"	8.25"	8.64"	9"	9.42"

## **RULER**

							P									
0"	CIRCUMFERENCE	3.93"	4.32"	<b>4.71"</b>	5.1"	5.5"	<b>5.89"</b>	6.28"	6.68"	7.0"	7.46"	7.85"	8.25"	8.64"	<b>9"</b>	9.42"
	CLAMP SIZE	1.25"	1.375"	1.5"	1.625"	1.75"	1.875"	2"	2.125"	2.25"	2.375"	2.5"	2.625"	2.75"	2.875"	3"



