WS 62 Repair Instructions

To replace the leather plunger washer (#11)

Unscrew the spout body & spout assembly (#14) from the barrel assembly (#15). (As sealant has been used on the thread, run the spout body under hot water and then tap it gently with a soft-headed mallet or a piece of soft wood. Place the pump vertically in a bench vice, gripping the barrel assembly below the flange.) DO NOT use too much force on the spout & DO NOT use any tools as they may cause damage to the barrel. The complete handle & plunger assembly can now be removed. By holding the plunger valve body (#13) in a bench vice, the valve seat (#12) can be unscrewed, enabling the leather cup washer to be replaced.

To replace the gland packing on Mk 1 model

Unscrew the gland nut (#6) and remove the old gland packing before winding the replacement packing around the plunger tube (#8). Apply a little vaseline to the packing to help it seat itself in position.

To replace the felt packing (#18) & quad ring (#20) on Mk 2 model

The complete plunger valve assembly must be removed from the plunger tube (#8). Take care when fitting the quadring so as not to damage its inside edge.

If your pump is not leaking at the gland, there is no necessity to replace either of the above.

**In 2010, the leather plunger washer was upgraded to a new Nitrile rubber plunger washer.

This changed included the addition of a new brass threaded backing washer and valve seat. If repairing an old pump with the old leather plunger washer, you will need to purchase a conversion kit WSP-62/22, including the new brass parts, in order to use the WSK-62A new spares kit with rubber plunger washer.

WS 62 **TUTSPIAU** CLASSIC LEVER GALLEY PUMP WS 62/1 HANDLE WS 62/5 HANDLE ASSEMBLY PLUNGER TOP WS 62/6 GLAND NUT WS 62/18 FELT PACKING WS 62/2-HANDLE LINK WS 62/19 BRASSWASHER WS 62/20 QUAD RING WS 62/7 COLLAR LINK RING WS 62/3 SWIVEL COLLAR WS 62/14 SPOUT BODY & SPOUT WS 62/15 WS 62/8 PLUNGER TUBE BARREL COMPLETE WS 62/13 PLUNGER VALVE BODY WS 62/9 STAINLESS STEEL BALL WS 62/10A THREADED BACKING WASHER WS 62/16 FLANGE NUT WS 62/11A NITRILE WASHER WS 62/12A VALVE SEAT

WSK-62A Spares Kit includes Part #11A, 18, and 20 WSP-62/22 Conversion Kit includes Part #10A & 12A Old Pre-1997 MK1 Gland Packing Cord is Part #WSP-62/21