

Heavy Duty Mechanical Suspension

Hardware Bag:

1. 8ea. 1" Hex Bolts
2. 4ea. 1-3/4" Phillips Flat Head Screws
3. 12ea. 1/4" Flat Washers
4. 4ea. 1/4" Flat Lock Washers
5. 4ea. 1/4" Countersunk Lock Washers
6. 4ea. 1/4" Nylock Nuts
7. 4ea. 5/16" Nylock Nuts



Installation: (Note: *Leave everything loose on slider and adapter until installed*)

1. Install adapters on seat bottom



4ea 1-3/4" Phillips Flat Screws

4ea 1/4" Countersunk Lock Washers

Note: T-nuts face the wood on the bottom of the seat

2. Install Sliders to adapters



Visual of the layout of Adapter and Slider

4ea 1" Hex Bolts
4ea 1/4" Flat Lock Washers
4ea 1/4" Flat Washers



Adjustment lever goes on left side if you are sitting in the seat

*Notice where adjustment rod installs on lever side



Placement of adjustment rod on opposite side



How it should look when finished
(Tighten down all Screws and Bolts
– NOT the 5/16" Nylocks)

*Notice where the 4ea 5/16"
Nylock nuts go on end of slider
posts

3. Install Swivel to top of Heavy Duty Mech. Suspension



4ea 1" Hex Bolts
8ea 1/4" Flat Washers
4ea 1/4" Nylock Nuts



Rotate Swivel to give access
to the bolt holes when
installing both the swivel to
the HDMS and the seat with
slider to the swivel